Tip *Using the TL-N044-000-R for checking premise wiring*

Patch Cord

Patch Panel

Horizontal Runs

Unshielded or Shielded Twisted Pair

Wall Plate

Patch Cord

Remote Unit LEDs light up as it receives signal through each conductor.

Master unit sends signal through premise wiring. LEDs light as it steps through each conductor.