

Comes complete with male and female 4-40 hardware.

## STEP 1



This cable is shipped with male knurled thumbscrews regardless of D-Sub gender.

## STEP 2



If you need a female fastening system, simply unscrew the knurled thumbscrew.

## STEP 3



Then: install (thread) hex jack screws provided with an instruction sheet.

## STEP 4



To install your cable on a panel it should be no thicker than 0.062". Simply follow step 2. Provide proper panel opening, install the hex jack screw and tighten.